

NATURAL RESOURCES CONSERVATION SERVICE
CONSERVATION PRACTICE STANDARD

CONTOUR FARMING

(Acre)
Code 330



DEFINITION

Aligning ridges, furrows, and roughness formed by tillage, planting and other operations to alter velocity and/or direction of water flow to around the hillslope.

PURPOSE

This practice is applied to achieve one or more of the following:

- Reduce sheet and rill erosion - Resource Concern (SOIL EROSION – Sheet, rill, & wind erosion).
- Reduce transport of sediment, other solids and the contaminants attached to them - Resource Concern (SOIL EROSION – Sheet, rill, & wind erosion).
- Reduce transport of contaminants found in solution runoff - Resource Concern (WATER QUALITY DEGRADATION – Excess nutrients in surface and ground waters; Pesticides transported to surface and ground waters; Excess pathogens and chemicals from manure, bio-solids or compost applications).
- Increase water infiltration – Resource Concern (INSUFFICIENT WATER - Inefficient Moisture Management).

CONDITIONS WHERE PRACTICE APPLIES

This practice applies on sloping land where annual crops are grown.

CRITERIA**General Criteria Applicable to All Purposes**

Follow all federal, state and local laws, rules and regulations.

Impact to cultural resources, wetlands, and Federal and State protected species needs to be determined prior to implementation of this practice. Any impacts need to be avoided or minimized to the extent practical during planning, design and implementation of this conservation practice in accordance with established National and Florida NRCS policy, General Manual (GM) Title 420-Part 401, Title 450-Part 401, and Title 190-Parts 410.22 and 410.26; National Planning Procedures Handbook (NPPH) FL Supplements to Parts 600.1 and 600.6; National Cultural Resources Procedures Handbook (NCRPH); and The National Environmental Compliance Handbook (NECH).

Minimum Row Grade. The crop rows need to have sufficient grade to ensure that runoff water does not pond and cause unacceptable crop damage.

Maximum Row Grade. The maximum row grade should not exceed one-half of the up-and-down hill slope percent used for conservation planning with a maximum 4 percent row grade.

Up to a 25% deviation from the design row grade is permitted within 150 feet of a stable outlet.

When the row grade reaches the maximum allowable design grade, establish a new baseline up or down slope from the last contour line, and use this new baseline for layout of the next contour pattern. All tillage and planting operations need to follow the contour line established.

Minimum Ridge Height.

- **Row spacing greater than 10 inches.**
The minimum ridge height should be 2 inches during the period of the rotation that is most vulnerable to sheet and rill erosion. Use current approved water erosion prediction technology to determine desired ridge height.
- **Row spacing 10 inches or less.** The minimum ridge height should be one inch for close-grown crops, such as small grains. Plants need to be at least 6 inches high and the spacing between plants within the row should not be greater than 2 inches during the time most vulnerable to sheet and rill erosion.

The minimum ridge height criteria are not required when the Florida NRCS Conservation Practice Standard [Residue and Tillage Management, No-Till, Code 329](#), is used on the contour and at least 50 percent surface residue cover is present between the rows after planting. See Florida NRCS Conservation Practice Standard [Residue and Tillage Management, No-Till, Code 329](#), for further guidance.

Stable Outlets. Surface flow from contoured fields shall be delivered to stable outlets.

Additional Criteria to Increase Water Infiltration

Row Grade. The maximum row grade should not exceed 0.2%.

CONSIDERATIONS

General. Several factors influence the effectiveness of contour farming to reduce soil erosion. These factors include: 10-year, 24-hour rainfall in inches; ridge height; row grade; slope steepness; soil hydrologic group; cover and roughness; and slope length. Cover and roughness,

row grade and ridge height can be influenced by management and provide more or less benefit depending on design.

Contour farming is most effective on slopes between 2% and 10%. This practice will be less effective in achieving the stated purpose(s) on slopes >10% and in areas with 10-year, 24-hour rainfall of about 6.5 inches. The practice is not well suited to rolling topography having a high degree of slope irregularity because of the difficulty meeting row grade criteria.

This practice is most effective on slopes between 100- and 400-feet long. On slopes longer than 400 feet, the volume and velocity of overland flow exceeds the capacity of the contour ridges to contain them. Increasing residue cover and roughness will change the vegetative cover-management conditions and decrease overland flow velocities, thus increasing the slope length at which this practice is effective. Increasing roughness alone is not sufficient to produce this effect.

The closer the row grade is to the true contour, the greater will be the erosion reduction. "Absolute row grade" should be selected rather than "relative row grade" in the supporting practices step of RUSLE2 when designing contour strips.

Prior to design and layout, obstruction removal and changes to field boundaries or shape should be considered, where feasible, to improve the effectiveness of the practice and the ease of performing farming operations.

When the intersection of crop rows with the field edge is not perpendicular, a field border, (see Florida NRCS Conservation Practice Standard [Field Border, Code 386](#)), may be needed to allow farm implements room to turn and control erosion along the field border.

If using ridge till on the contour, avoid crossing over ridged rows at correction areas because this will destroy the effectiveness of the ridges. Sod turn strips may be established if correction areas are unavoidable.

The width of correction areas, and the distance between baselines, should be adjusted for equipment operation widths.

Ridge Height. Ridge height is created by the operation of tillage and planting equipment. The greater the ridge height, the more effective the operation is in slowing overland flow. The RUSLE2 Operations database contains the ridge height value for each field operation.

Stable Outlets. Grassed waterways, water and sediment control basins, underground outlets, or other suitable practices should be used to protect areas of existing or potential concentrated flow erosion. See Florida NRCS Conservation Practice Standards [Grassed Waterway, Code 412](#); [Field Borders, Code 386](#); [Sediment Basin, Code 350](#); [Terrace, Code 600](#); and [Diversion, Code 362](#), for more information.

PLANS AND SPECIFICATIONS

Prepare specifications for establishment and operation of this practice for each field according to the Criteria, Considerations, and Operation and Maintenance described in this standard. At a minimum the plans need to include:

- Percent land slope used for conservation planning;
- The minimum and maximum allowable row grades for the contour system;
- A sketch map or photograph of the field showing:
 - approximate location of the baselines used to establish the system,
 - location of stable outlets for the system, and
 - acres of the fields with contouring.

Record specifications using an approved implementation requirement document, narrative statements in the conservation plan, or other acceptable documentation.

OPERATION AND MAINTENANCE

Perform all tillage and planting operations parallel to contour baselines or terraces, diversions, or contour buffer strip boundaries where these practices are used, provided the applicable row grade criteria are met.

Where terraces, diversions, or contour buffer strips are not present, maintain contour markers on grades that, when followed during establishment of each crop, will maintain crop rows at designed grades. Contour markers may be field boundaries, a crop row left untilled near or on an original contour baseline or other readily identifiable, continuous, lasting marker. Perform all tillage and planting operations parallel to the established marker. If a marker is lost, re-establish a contour baseline within the applicable criteria set forth by this standard prior to seedbed preparation for the next crop.

Begin farming operations on the contour baselines and proceed up and down the slope in a parallel pattern until patterns meet. Where field operations begin to converge between two non-parallel contour baselines, establish a correction area that is either permanently in sod, or established to an annual close-grown crop.

Where contour row curvature becomes too sharp to keep machinery aligned with rows during field operations, establish sod turn strips on sharp ridge points or other odd areas as needed.

Renovate field borders as needed to maintain at least 65 percent ground cover. Maintain adequate field border width to allow farm implements room to turn. See Florida NRCS Conservation Practice Standard [Field Border, Code 386](#).

Consider the use of precision farming technologies to minimize compaction and to maintain alignment of the contour system.

REFERENCES

Foster, G.R. Revised Universal Soil Loss Equation, Version 2 (RUSLE2) Science Documentation (In Draft). USDA-ARS, Washington, DC.2005.

<http://fargo.nserl.purdue.edu/RUSLE2 ftp/RUSLE2 Program File/RUSLE2 Science Doc.pdf> (accessed April 23, 2014)

Renard, K.G., G.R. Foster, G.A. Weesies, D.K. McCool, and D.C. Yoder, coordinators. 1997. Predicting soil erosion by water: A guide to conservation planning with the Revised Universal Soil Loss Equation (RUSLE). U.S. Department of Agriculture, Agriculture Handbook 703. http://www.ars.usda.gov/SP2UserFiles/Place/64080530/RUSLE/AH_703.pdf (accessed April 23, 2014)